Backstamp for forks and spoons. Should be placed on the backside of the handle.

Stainless steel **IKEA** 000 00